






















P9


for Height adjustment if need



















if the boom can't set on the dock
then you must polish the bottom



Remove the cover plate and remove the main boom
then polish the main boom bottom



after use the new cover plate

